



MPG setup guide

Version: 23/7/2015

SAFETY INFORMATION





This product is intended for integration by the user into a computer numerical control (CNC) machine. It is the user's responsibility to assess the overall system design and address all safety considerations that affect the users and equipment. The user assumes all responsibility for system design, including compliance with regulatory standards and codes issued by the applicable entities. PoLabs do not make any claims as to the suitability of this equipment for the user's application. Serious personal injury or equipment damage can occur from the improper integration, installation or operation of this product.

This product is not guaranteed to be fail-safe. The system that this equipment is used with shall be fitted with a separate means of fail-safe protection, emergency-stop capability and/or system power removal. This equipment may be connected to dangerous power sources, including electrical power sources. Dangerous voltage levels may be present at this equipment or at connected devices. Measures must be taken to prevent persons from contacting voltage sources which may be present. Equipment should be housed inside an enclosure suitable for the intended environment. Safety interlocks should be provided to prevent any and all dangers to personnel.


CNC machine tools are inherently dangerous, and can cause injury to operators and maintenance personnel. Operators and maintenance personnel shall be properly trained in the safe use, operation and maintenance of such machines. Automated machines that this equipment may be used with can move at any time. All persons exposed to such machines must understand the dangers that are present.

PoKeys Mach3 plugin setup

Run Mach3 and under PlugIn Control tab select Configure PoKeys. This will open the Pokeys plugin configuration window.




In the PoKeys plugin configuration window select the Encoder settings tab.




In this example we used PoMPG2 connected on pin 1 which is channel A and pin 2 which is channel B. Normal encoders can be connected to any available pin. You just have to make sure you select the right pins for A and B output from encoder/MPG. Do not forget to power your MPG.

If you also have the Pulse engine enabled you must check the "Let PoKeys handle MPG jogging" check box.

PoKeys Pulse engine v2 documentation




You can also use fast and/or ultra fast encoders. In that case, the pins cannot be changed and are predefined. For available fast and ultra fast encoder pins please look at the PoKeys device user manual.




PoKeys Pulse engine v2 documentation

Next you must select the right DRO. For MPG1 select DRO 101, for MPG2 select DRO 102, for MPG3 select DRO 103. Remember which DRO you used as it will be needed in the Mach3 configuration later.




Now if you click on the PoKeys mapping tab in the plugin configuration window you should see the pins mapped to the correct function.




PoKeys Pulse engine v2 documentation

If you click on the Settings tab in Mach 3 (Alt-6), you should see the count value of the defined MPG change. If that is not the case please recheck the MPG connection to the PoKeys device and correct pin configurations.




Now in Mach 3 click on Config tab and select Ports and Pins. In the Ports & Pins window, click on the Encoder/MPG's tab. Here you must enable the MPG you previously defined with the DRO setting: MPG1->DRO 101, MPG2->DRO 102, MPG3->DRO 103. As we have selected the DRO 101 we enable the MPG #1.



Now bring up the pendant window in Mach 3 by pressing the Tab key on your keyboard.

Click on the Jog Mode button a few times until the MPG window becomes yellow. This will enable the MPG jogging. Next click on the Alt A, B or C button to select the axis you want to jog. The button depends on your DRO selection: A is for MPG1, B is for MPG2 and C is for MPG3.



If everything was configured correctly you should see the selected axis move as you turn the MPG. If not, please recheck all of the above steps to make sure you have configured everything correctly.

This example was done using only one MPG, you can have up to 3 connected. The configuration steps are the same for each one.

Please read the following notes

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice.
2. PoLabs does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of PoLabs products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of PoLabs or others. PoLabs claims the copyright of, and retains the rights to, all material (software, documents, etc.) contained in this release. You may copy and distribute the entire release in its original state, but must not copy individual items within the release other than for backup purposes.
3. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of the products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. PoLabs assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
4. PoLabs has used reasonable care in preparing the information included in this document, but PoLabs does not warrant that such information is error free. PoLabs assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
5. PoLabs devices may be used in equipment that does not impose a threat to human life in case of the malfunctioning, such as: computer interfaces, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment, and industrial robots.
6. Measures such as fail-safe function and redundant design should be taken to ensure reliability and safety when PoLabs devices are used for or in connection with equipment that requires higher reliability, for example: traffic control systems, anti-disaster systems, anticrime systems, safety equipment, medical equipment not specifically designed for life support, and other similar applications.
7. PoLabs devices shall not be used for or in connection with equipment that requires an extremely high level of reliability and safety, as for example: aircraft systems, aerospace equipment, nuclear reactor control systems, medical equipment or systems for life support (e.g. artificial life support devices or systems), and any other applications or purposes that pose a direct threat to human life.
8. You should use the PoLabs products described in this document within the range specified by PoLabs, especially with respect to the maximum rating, operating supply voltage range and other product characteristics. PoLabs shall have no liability for malfunctions or damages arising out of the use of PoLabs products beyond such specified ranges.
9. Although PoLabs endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, PoLabs products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a PoLabs product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures.
10. Usage: the software in this release is for use only with PoLabs products or with data collected using PoLabs products.
11. Fitness for purpose: no two applications are the same, so PoLabs cannot guarantee that its equipment or software is suitable for a given application. It is therefore the user's responsibility to ensure that the product is suitable for the user's application.
12. Viruses: this software was continuously monitored for viruses during production, however the user is responsible for virus checking the software once it is installed.
13. Upgrades: we provide upgrades, free of charge, from our web site at www.poscope.com. We reserve the right to charge for updates or replacements sent out on physical media.
14. Please contact a PoLabs support for details as to environmental matters such as the environmental compatibility of each PoLabs product. Please use PoLabs products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. PoLabs assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
15. Please contact a PoLabs support at support@poscope.com if you have any questions regarding the information contained in this document or PoLabs products, or if you have any other inquiries.
16. The licensee agrees to allow access to this software only to persons who have been informed of and agree to abide by these conditions.
17. Trademarks: Windows is a registered trademark of Microsoft Corporation. PoKeys, PoKeys55, PoKeys56U, PoKeys56E, PoScope, PoLabs and others are internationally registered trademarks.